

# Dicing Saw

---

## Standard Operating Procedure

---

*Revision: 1.0 — Last Updated: Apr. 15/2015, Revised by Mohamad Rezaei*

---

### Overview

This document will provide a detailed operation procedure of the Dicing Saw. Formal Training is required for all users prior to using the system.

### Revision History

#	Revised by:	Date	Modification
1	Mohamad Rezaei	April 15, 2015	Initial release
2			
3			
4			
5			

Document No. -----

## Table of Contents

Overview.....	1
Revision History.....	1
Table of Contents.....	2
General Information .....	3
Operation .....	4
1. Start-up .....	4
2. Programming.....	5
3. Operation .....	8
4. Dual Axis cutting.....	9
5. Shut-down .....	9
References and Files .....	10
Contact Information .....	10

## General Information


The Loadpoint MicroAce Series 3 is an ultra-high – precision, high speed cutting and scribing machine.



## Operation

### 1. Start-up


- Turn on the chiller.



- Open the air valve at the backside of the machine.



- Turn on the main isolator switch on the front of the main unit.



- Press the white start button adjacent to the emergency stop.



- Turn on two black switches on the wall



## 2. Programming


- Place the sample on the rotary porous chuck
- Press **prog** on the control panel. The red indicator light "**• programme no**" starts flashing.



- If you already have a saved program, select it, otherwise enter 32 by pressing **3**, **2** and **enter**.
- The next light on the Auto Prompt "**• inch [1]/ metric [2]**" then flashes. Select either **1** for inch or **2** for metric and press **enter**.
- The "**• mode**" now flashes. Programme modes for wafer shape with single or multiple passes and with manual or automatic operation are available on the panel above the controller. Select a suitable mode based upon your dicing plan.


**NOTE: Please select a number from "SINGLE PASS MODE" column. For a dual axis cutting use an "auto cut" mode. In mono modes the blade cuts only in one direction while in bi-direction modes the blade cut in 2 directions.**

CUT SHAPE	SINGLE PASS MODE	MULTI PASS MODE
Rectangular	11 mono 12 bi-direction 13 auto mono 14 auto bi-dir	41 mono 42 bi-direction 43 auto mono 44 auto bi-dir
Circular	21 mono 22 bi-direction 23 auto mono 24 auto bi-dir	51 mono 52 bi-direction 53 auto mono 54 auto bi-dir
Hexagonal	31 mono 32 bi-direction 33 auto mono 34 auto bi-dir 35 pattern mono 36 pattern bi-dir	61 mono 62 bi-direction 63 auto mono 64 auto bi-dir 65 pattern mono 66 pattern bi-dir
Blade dressing Special Mode 00 programmes 81 & 82		
ERROR CODES		
01 Emergency stop	08 Spindle not selected	
02 Inverter ready loss	09 Overrun of Y limits	
03 Low air pressure	10 Inch/metric not selected	
04 Low water pressure	11 Data below minimum limit	
05 Low vacuum pressure	12 Data above maximum limit	
06 Vacuum chuck not on	13 Invalid mode data	
07 Not height sensed	14 Over X limits	
	15 Low water flow rate	



- The “• **dimension A**” then flashes. **dimension A** displays the work piece dimension along the Y-axis when the chuck is in the 0 position ready for pass A. key in your dimension and press **enter**.
- The “• **dimension B**” then flashes. **dimension B** displays the work piece dimension along the X-axis when the chuck is in the 0 position ready for pass A. key in your dimension and press **enter**.

**Note:** Whenever vacuum “vac” is turned on, the Data Panel will display the current pass.



- The “• **compt thickness**” then flashes. **compt thickness** displays the thickness entered for the component, which should include the thickness of the mounting film. Enter proper thickness and press **enter**.
- The “• **depth of cut**” then flashes. Enter the desired depth which always should be less than the thickness of the components.
- Enter the “• **pitch A**” value. **pitch A** displays the pitch, or index increment, on the Y-axis when the chuck is in pass A.
- Enter the “• **pitch B**” value. **pitch B** displays the pitch, or index increment, on the Y-axis when the chuck is in pass B.
- Enter the “• **no of cuts A**” value. It displays the number of cuts when the chuck is in the A pass.
- Enter the “• **no of cuts B**” value. It displays the number of cuts when the chuck is in the B pass.
- Enter the “• **feed rate-left**” value. It shows the carriage speed for a right to left cut.

- Enter the “• **feed rate-right**” value. It shows the carriage speed for a left to right cut.
- Enter the “• **spindle speed (r.pm)**” value. Key in 40 for a spindle speed of 40,000 rpm and press **enter**.
- Programming is now complete. To save data press **save** & the button with no label shown in the below image simultaneously.




### 3. Operation

After programming the machine

- Place the mounted work piece over the chuck
- Press **vac** and do the alignment procedure as described below
  - Use the jog keys to generally align the work piece
  - Using the microscope, jog the X, Y and  $\ominus$  keys to precisely align the work piece
  - The first cut is now aligned to the blade
- Press **spindle** to start
- Press **height sense**. [HS] is displayed in the DATA panel. Wait till [HS] is cleared from the Data panel.
- Press **cut auto**. The cutting programme will now start.

**Note: Check that operation is satisfactory and that blade coolant is spraying tangentially onto the point of contact of the blade.**





- On the completion of the programme, [END] will show.

#### 4. Dual Axis cutting

Dual axis cutting automatically cuts the second axis

- Select and enter a suitable programme with an **auto cut** mode.
- Start **spindle** and **height sense**.
- Follow the general guide until the work piece is aligned on the first pass. Ensure work piece is in correct orientation for pass A or Pass B.
- Press **cut auto**. The machine will now remember that position and rotate the chuck through 90°.
- Align the work piece on the second pass and press **cut auto**.
- The machine will now start cutting the second pass. On completion, the chuck will rotate back through 90° and move to the memorized alignment position of the first pass and start cutting the first pass.

#### 5. Shut-down

- If spindle is rotating press **spindle** to stop.
- Turn off the main isolator switch on the front of the main unit.
- Close the air valve at the backside of the machine.
- Turn off the chiller
- Wait for 5 minutes and then turn off two black switches on the wall

## References and Files

MicroAce 3 operation and maintenance manual and training notes.

## Contact Information

Questions or comments in regard to this document should be directed towards Mohamad Rezaei ([rezaei@4dlabs.ca](mailto:rezaei@4dlabs.ca)) in 4D LABS at Simon Fraser University, Burnaby, BC, Canada.